

Assembly Instructions

READ THROUGH THESE INSTRUCTIONS PRIOR TO STARTING ASSEMBLY.

Document Instructions



Use Document #1016014 with fastener kits 879438 and 879439. These kits are to be used with the Vektor-CD model. The fasteners contained within the kit are to be used to attach the windband to the Vektor-CD nozzle. Use the images located within this document to locate the position of the fasteners on the unit.

Assembly Instructions

1. See Greenheck Document #471555 (Installation, Operation and Maintenance Manual: Vektor-CD, Vektor-CH and Vektor-CS) for full installation instructions.
2. See image to the right to locate bolt holes. Install moly-coated 316 stainless steel screws (provided) in all holes to secure the windband to the nozzle.

Tools Required

- Cordless drill (electric or pneumatic)
- 9/16 inch nut setter
- 9/16 inch wrench



FASTENER KIT 879438 – VEKTOR-CD SIZE 12-24

Part Description	Part #	Quantity
CS,HH,.375-16X1.5,SS,316,MOLY	415781	8
NUT,HEX,.375-16,SS,316	415799	8
WSHR,FLAT,.313X.05X.406X.875,SS,316	415800	16
WSHR,LOCK,SPLIT,.375,SS,316	415810	8
Assembly Instructions	1016014	1

FASTENER KIT 879439 – VEKTOR-CD SIZE 27-66

Part Description	Part #	Quantity
CS,HH,.375-16X1.5,SS,316,MOLY	415781	12
NUT,HEX,.375-16,SS,316	415799	12
WSHR,FLAT,.313X.05X.406X.875,SS,316	415800	24
WSHR,LOCK,SPLIT,.375,SS,316	415810	12
Assembly Instructions	1016014	1