



Square Retrofit Air Terminal



Control Panel [Std]
Shown With Dust Cover



Available Sizes

Width		Height	
Min.	Max.	Min.	Max.
6" [152]	36" [914]	6" [152]	24" [610]

The standard location for control panel is Right Hand on Square Retrofit Air Terminal

Looking in the direction of airflow, the control panel is on the right.

Standard Construction

- | | | |
|---|--|---|
| <ul style="list-style-type: none"> • 1/2" Dual Density, Coated Fiberglass • All Insulations Meet NFPA 90A And UL 181 • All Fiberglass Insulations Have Coated Edges To Prevent Fiber Migration | <ul style="list-style-type: none"> • Units Are Constructed With 20 Gauge Frame & 18 Gauge Damper Blade(s) | <ul style="list-style-type: none"> • Inlet Airflow Sensor • Control Panel with Dust Cover |
|---|--|---|