


Square Retrofit Air Terminal


Available Sizes

| Width | | Height | |
|----------|-----------|----------|-----------|
| Min. | Max. | Min. | Max. |
| 6" [152] | 36" [914] | 6" [152] | 24" [610] |

The standard location for control panel is Right Hand on Square Retrofit Air Terminal

Looking in the direction of airflow, the control panel is on the right.

| Standard Construction | | |
|---|--|---|
| <ul style="list-style-type: none"> • 1/2" Dual Density, Coated Fiberglass • All Insulations Meet NFPA 90A And UL 181 • All Fiberglass Insulations Have Coated Edges To Prevent Fiber Migration | <ul style="list-style-type: none"> • Units Are Constructed With 20 Gauge Frame & 18 Gauge Damper Blade(s) | <ul style="list-style-type: none"> • Inlet Airflow Sensor • Control Panel with Dust Cover |