


Retrofit Rectangular Exhaust Air Terminal Unit



Available Sizes

Width		Height	
Min.	Max.	Min.	Max.
6" [152]	36" [914]	6" [152]	24" [610]

The standard location for control panel is Right Hand on Square Retrofit Air Terminal. Looking in the direction of airflow, the control panel is on the right.

Standard Construction		
<ul style="list-style-type: none"> • 1/2" Dual Density, Coated Fiberglass • All Insulations Meet NFPA 90A And UL 181 • All Fiberglass Insulations Have Coated Edges To Prevent Fiber Migration 	<ul style="list-style-type: none"> • Units Are Constructed With 22 Gauge Frame & 18 Gauge Damper Blade(s) 	<ul style="list-style-type: none"> • Inlet Airflow Sensor • Control Panel with Dust Cover